

Park Avenue 3-Way Assembly Instructions

1. Attach casters to bottom of frame base.

2. Slide frame upright over attachments and attach frame base using 2 screws.

NOTE: Leave screws loose for adjustment DO NOT TIGHTEN

3. Attach cross bars at top between uprights using 2 screws.

NOTE: Leave screws loose for adjustment. TIGHTEN WHEN COMPLETE

- 4. Slide shelf into base frame, matching peg in base with hole in bottom of shelf.
- 5. Slide brackets into slots in uprights, position parralel, repeat as needed.
- 6. Slide hangbar or shelves over pegs in brackets until secure.
- 7. Slide peghooks and or faceouts over hangbar and position as needed.
- 8. Slide signholder into cneter slot in top crossbar, slide acrylic insert into slot in top of signholder.

