



PALAY DISPLAY

The Park Avenue Collection



Park Avenue Outrigger Assembly Instructions

1. Place upright on floor with side detail facing up.
2. Align wallmount bracket at top.
3. Insert top plate into top of upright.
4. Apply front plate over screw holes at top of upright.
5. Insert hexhead bolts through front plate, upright, top plate and into wallmount bracket and thread until tight.
6. Insert floormount plate into bottom of upright.
7. Apply front plate over screw holes at bottom of upright.
8. Insert hexhead bolts through front plate, upright, and into floormount plate and thread until tight.
9. Stand outrigger upright and place against wall at stud location.
10. Repeat steps 1-9 for each additional upright and lean against wall 48" apart.
11. Secure screws through wallmount plate into wall stud. **NOTE: Leave screws loose for adjustment DO NOT TIGHTEN**
12. Slide brackets into slots in uprights, position parallel, repeat as needed..
13. Slide hangbar or shelves over pegs in brackets until secure, adjust distance between uprights as needed to accomodate **TWO BRACKETS PER upright SLOT.**
14. Secure screws through wallmount plate into wall stud and tighten.
15. Check for level and adjust floormount plate accordingly.
16. Secure screws through floormount plate into floor until tight.

