

Park Avenue 2 Way Assembly Instructions

- 1. Attach casters to bottom of frame base.
- 2. Slide frame upright over attachments and attach frame base using 2 screws.

NOTE: Leave screws loose for adjustment. DO NOT TIGHTEN

- 3. Attach cross bar at top between uprights using 2 screws.
- 4. Slide base shelf into base frame, matching peg in base with hole in bottom of shelf.
- 5. Slide hangrail brackets into slots in uprights, position parralel, repeat as needed.
- 6. Slide hangbar over pegs in brackets until secure.
- 7. Slide peghooks and or faceouts over hangbar and position as needed.
- 8. Slide signholder into center slot in top crossbar, slide acrylic insert into slot in top of signholder.

