
Palay Display 800-446-6106



- 1. Slide one of the legs through lower fitting on side frame. Align hole in fitting with hole in leg and secure it loosely with a bolt. Repeat for the other leg and side frame. NOTE: The 90 degree fitting on the leg should be pointing down.
- 2. Loosely secure the cross support as shown with (1) bolt.
- 3. Secure the other side assembly from step 1 with remaining bolts as shown. NOTE: The bolts from previous steps should be tightened now.
- 4. Thread the casters into the 90 degree fittings on the legs.
- 5. Loosen all (4) hand wheels to install hang bars as show. Tighten the handwheels to clamp the hang bars at desiered height.