


Gridwall Kiosk Wall Assembly Instructions - 20ft



First construct 10 ft wall:

Step 1: With 3 connectors per edge, assemble 2 panels into acute angle as shown in center section.

Step 2: Assemble 2 panels into 90-degree corner. Repeat for opposite end.

Step 3: Add panel between assembled parts from steps 1 and 2.

To complete 20 ft wall:

Repeat steps 1-3 using end panel of first section as one end of new section.

Outfit with gridwall accessories to create your ideal display wall.

Please note: These grid kiosks are intended for display and merchandising items such as clothing and giftware. If using with heavyweight items or outdoor displaying where weather can be a factor, additional bracing or anchoring may be needed. Please consult your Palay Display representative for more information.

10901 LOUISIANA AVE, S.
BLOOMINGTON, MN 55438

pd **PALAY DISPLAY**
STORE FIXTURES AND SUPPLIES SINCE 1945

PHONE: 952-983-2026
TOLL FREE: 800-446-6106
www.palaydisplay.com