


Gridwall Kiosk Wall Assembly Instructions - 10ft



Step 1: With 3 connectors per edge, assemble 2 panels into acute angle as shown in center section.

Step 2: Assemble 2 panels into 90-degree corner. Repeat for opposite end.

Step 3: Add panel between assembled parts from steps 1 and 2.

Outfit with gridwall accessories to create your ideal display wall.

Please note: These grid kiosks are intended for display and merchandising items such as clothing and giftware. If using with heavyweight items or outdoor displaying where weather can be a factor, additional bracing or anchoring may be needed. Please consult your Palay Display representative for more information.



PALAY DISPLAY
STORE FIXTURES AND SUPPLIES SINCE 1945

10901 LOUISIANA AVE, S.
BLOOMINGTON, MN 55438

PHONE: 952-983-2026
TOLL FREE: 800-446-6106
www.palaydisplay.com