


Gridwall Mall Kiosk Assembly Instructions



Step 1: Using 3 connectors, assemble a pair of gridwall panels at a 90-degree angle and secure in place with a corner shelf. Repeat 3 times for a total of 4 corner assemblies.

Step 2: Assemble rear center "T" shape using 2 panels as shown. Connect to rear corners by filling gap with an additional grid panel on either side of "T" as well as a corner shelf on "T" pair.

Step 3: Add an additional panel to front and rear corner assemblies on left and right sides, and add a small support panel to each new panel as shown.

Step 4: Complete construction by adding the center panels on left and right sides.

Outfit with gridwall accessories (sold separately) to create your ideal kiosk.

Please note: These grid kiosks are intended for display and merchandising items such as clothing and giftware. If using with heavyweight items or outdoor displaying where weather can be a factor, additional bracing or anchoring may be needed. Please consult your Palay Display representative for more information.

10901 LOUISIANA AVE, S.
BLOOMINGTON, MN 55438

 **PALAY DISPLAY**
STORE FIXTURES AND SUPPLIES SINCE 1945

PHONE: 952-983-2026
TOLL FREE: 800-446-6106
www.palaydisplay.com