

Grid Gondola Assembly Instructions



1. Assemble base as shown using the provided allen wrench and bolts. Casters screw into base.

2. Using a screwdriver and supplied connectors, connect one end grid panel to one middle panel. Use three connectors.

3. Set pair of assembled grid panels onto base, and attach using screws.

4. Repeat steps 2 and 3 for other pair of grid panels. Connect two center panels together using three connectors, and fasten to base with screws.



PALAY DISPLAY

STORE FIXTURES AND SUPPLIES SINCE 1945

10901 LOUISIANA AVE, S. PHONE: 952-983-2026
BLOOMINGTON, MN 55438 TOLL FREE: 800-446-6106
www.palaydisplay.com